Care Information

Polygloss SR, Polymatt SR, Polygloss Dekor

No aggressive cleaning agents must be used on any material surface, whether wood, laminate or foil. Aggressive cleaning agents include abrasive products as well as products with a high acid content or self-cleaning properties. Cleaning products containing highly volatile solvents are not recommended either. They may be too strong for the surface coating on fronts and cause damage over time.

For this reason, do not apply any abrasives, furniture polish, floor wax, cellulose and synthetic-resin thinners, acetone or similar cleaning products. Do not use steel wool or sponge scourers either.

Under no circumstances should the surfaces on fronts be treated with steam cleaners. Over time, moisture penetrating the surface may result in damage.
Abrasive cleaning cloths must be avoided. This also includes the back of normal dishwashing sponges as they can leave scratches.

To avoid damaging any of the surfaces, only remove the protective films once the furniture has been assembled.

To clean the surfaces, you need nothing else than a soft cloth and warm water with a few drops of detergent or glass cleaner. After cleaning, it is important to wipe dry with a soft cloth, preferably a microfibre cloth.

Stains, particularly those caused by strongly dyed substances and liquids, as well as splashes of fat etc., must be removed with plenty of water, if necessary adding a quantity of ordinary, non-abrasive household cleaner. After cleaning, remove any soap residue with lukewarm water and rub dry with a chamois leather. Stains should not be allowed to dry. It may no longer be possible to remove dried-on substances or substances that have been allowed to penetrate over a prolonged period of time.

Particularly stubborn stains can be removed using ordinary plastic cleaner or glass cleaner . Before applying, it is advisable to test the cleaning product on a non-visible area first.

This care information is based on the latest knowledge and experience .