

CARE AND MAINTENANCE

SLIGHTLY DIRTY

Cleaning can be done with a soft paper towel or a non-abrasive sponge.

The subsequent drying should be done

with absorbent paper or a microfiber towel

NORMAL DIRT

Cleaning can be done with warm water

using a microfiber towel, a soft sponge or a soft brush.

You can resort to the use of detergents or household soaps, avoid products with abrasive action.

Once the detergent is applied, clean with fresh water to prevent streaking.

Final drying can be done with an absorbent towel or absorbent paper.

VERY DIRTY

Very dirty spots must be removed quickly to avoid the possibility of damaging the surface by the action of dirt agents.

Avoid the use of aggressive and abrasive agents, rough towels or abrasive sponges that, while removing dirt and grease, could irreparably damage the surface.

To avoid:

Bleach, high concentration alcohol, caustic soda detergents, abrasive degreasers,

cleaners such as abrasive towels and sponges, acid-based cleaners, steam cleaners, thinners, acetone.

Non-respect of these rules could cause irreversible damage to the surface